

INSTRUCTION MANUAL INSERT FOR **RUGER® LCP® CUSTOM**



NOTE: The front sight is permanently mounted and should not be removed by the consumer. Please refer to the enclosed instruction manual for all other operations.

SUPPLEMENTAL PARTS LIST

Please See Pages 28 & 29 of the Enclosed Instruction Manual For Additional Parts List and Exploded View Drawing

Key	Part Name	Part No.
* 1	Slide	SC00106
2	Front Sight	SC03200
3	Front Sight Screw	SC07600
4	Guide Rod	SC02010
5	Trigger, Aluminum	SC03901
6	Rear Sight	SC03300
7	Rear Sight Screw	SC08001

* Parts so marked must be factory installed.

